

Programmable AC Power Source

APS-7051/APS-7101

USER MANUAL



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Table of Contents

SAFETY INSTRUCTIONS	4
GETTING STARTED	8
APS-7000 Series Overview.....	9
Appearance.....	12
OPERATION	18
Set Up.....	20
Basic Operation	40
Preset Settings.....	56
Test Mode Function	60
COMMUNICATION INTERFACE	70
Interface Configuration	71
FAQ	90
APPENDIX	92
Firmware Update	92
APS-7000 Default Settings	94
APS-7000 Specifications.....	95
APS-7000 Dimensions.....	98
INDEX	100

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.



Warning: Identifies conditions or practices that could result in injury or loss of life.



Caution: Identifies conditions or practices that could result in damage to the APS-7000 or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



CAUTION

- Do not place any heavy object on the APS-7000.
- Avoid severe impact or rough handling that leads to damaging the APS-7000.
- Do not discharge static electricity to the APS-7000.
- Use only mating connectors, not bare wires, for the terminals.
- Do not block the cooling fan opening.
- Do not disassemble the APS-7000 unless you are qualified.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. The APS-7000 doesn't fall under category II, III or IV.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- 0 is for measurements performed on circuits not directly connected to Mains.

Power Supply



WARNING

- AC Input voltage range: 115/230 Vac \pm 15%
 - Frequency: 50/60Hz
 - To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.
-

- Cleaning the APS-7000
- Disconnect the power cord before cleaning.
 - Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
 - Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.
-

Operation Environment

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity: 20%~ 80%, no condensation
- Altitude: < 2000m
- Temperature: 0°C to 40°C

(Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The APS-7000 falls under degree 2.

Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
 - Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
 - Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.
-

Storage environment

- Location: Indoor
 - Temperature: -10°C to 70°C
 - Relative Humidity: ≤80%, no condensation
-

Disposal



Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

Power cord for the United Kingdom

When using the instrument in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons



WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/ Yellow:	Earth
Blue:	Neutral
Brown:	Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol  or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

GETTING STARTED

This chapter describes the power source in a nutshell, including its main features and front / rear panel introduction.



APS-7000 Series Overview	9
Series lineup	9
Operating Area	9
Main Features	10
Accessories	11
Appearance.....	12
Front Panel.....	12
Rear Panel.....	15
APS-7051	15
APS-7101	15
Status Bar Icons.....	17


APS-7000 Series Overview

Series lineup


The APS-7000 series consists of 2 models, the APS-7051 and the APS-7101, differing only in capacity. Note that throughout the user manual, the term “APS-7000” refers to both the APS-7051 and APS-7101, unless stated otherwise.

Model name	Max. Output Current	Power Rating	Output Voltage
APS-7051	2.5A/1.25A/0.63A	500VA	0~1000 Vrms
APS-7101	5.0A/2.5A/1.25A	1000VA	0~1000 Vrms

Operating Area



APS-7101 Output Operating Area



Main Features

Performance

- Low output ripple and noise
- Excellent and feature-rich measurement capacity
- Standard maximum output voltage is 1000Vrms
- Maximum frequency of 500Hz.

Features

- OCP, OPP and OTP protection
- Variable voltage, frequency and current limiter
- Test function to simulate line voltage and frequency variations
- Large 4.3 inch TFT panel
- Globally adjustable power inlet not restricted by the power supply environment
- USB interface is equipped as standard with the

ability to upgrade the software.

- Only 88mm (2U) case height.

Interface • USB host


Accessories



Standard Accessories	Part number	Description
	CD ROM	User manual
	Region dependent	Type I Power cord (APS-7051)
	Region dependent	Type II Power cord (APS-7101)
	62PS-7K0SC701 x1 5302-01613001 x1	Mains terminal cover set (APS-7051)
	62PS-7K0SC401 x1 5302-01613001 x2	Mains terminal cover set (APS-7101)
Optional Accessories	Part number	Description
	GRA-423	APS-7000 rack mount kit
	APS-001	GPIB interface card
	APS-002	RS-232 / USB interface card
Download	Name	Description
	gw_aps.inf	USB driver



Appearance



Front Panel

APS-7051, APS-7101




Item	Description
Power Switch	<p>POWER</p>  <p>Turns on the mains power.</p>
Front Voltage Output Socket	<p>OUTPUT AC 250V MAX.</p>  <p>Output voltage terminal using a regional universal plug. There is a Euro and a Universal regional plug.</p> <p>For voltages exceeding 250Vrms, please use the rear output terminal.</p> <p>CAUTION</p>

USB A Port		The USB port is used for upgrading software.
LCD Screen		Displays the measured values or menu system.
Display Mode Select Key		Selects between Standard mode and Simple mode.
Function Keys		Assigned to the functions displayed on the right-hand side of the screen.
Menu Key		Enters the Main menu or goes back to one of the display modes.
Test Key		Puts the instrument into the Test mode.
Preset Key		Puts the instrument into Preset mode.
Arrow Keys		The arrow keys are used to select the digit power of a value that is being edited.
V		Used for setting the output voltage.
V-Limit	(Shift + V)	Used for setting the output voltage limit value.
F		Used for setting the output frequency.
F-Limit	(Shift + F)	Used for setting the output frequency limit value.
I rms		Used for setting the maximum output current.
IPK-Limit	(Shift + I rms)	Used to set the peak output current limit value.


Range Key		Switches between the 155V and 310V ranges.
Scroll Wheel		Used to navigate menu items or for incrementing/decrementing values one step at a time.
Lock Key		Locks the number pad to prevent accidentally changing panel settings.
Unlock Key (Long press)		Disables the key lock.
Enter Key		Confirms selections / settings
Cancel Key		Clears entries that are made in the number entry dialog when a value is edited using the arrow keys or the scroll wheel. The Cancel key can also be used to cancel function setting menus or dialogs.
Shift Key		Turns on the shift state, which enables shortcut operations.
Output Key		Turns the output on or off.
Number Pad		Used to enter values.
Local Mode	(Shift + 0)	Switches operation back to local mode from remote mode.
ALM CLR	(Shift + 6)	Clears alarms.
IPK CLR	(Shift + 9)	Clears peak current hold.

Rear Panel

APS-7051




APS-7101




Line Voltage Input

Voltage Input: 115/230±15% VAC; Line frequency: 50Hz/60 Hz (Automatically switchable)

APS-7051




APS-7101




Rear Voltage
Output Socket

Output voltage terminal.

APS-7051



APS-7101



FAN

Temperature controlled fan.


Ethernet Port



Optional
Interface Slot

Optional GPIB communication, RS-232/USB B communication and RS-232 communication.

Status Bar Icons



Indicates if the output is ON or OFF.



Indicates the output power as a percentage of full scale.



The alarm icon will appear on the status bar when one of the protection functions are tripped. Applies to Over Power, Over Irms, Over Ipeak and Over Temperature protection.



Indicates that a USB drive is detected in the front panel host port.



Indicates that the panel lock is active.

O PERATION

Set Up	20
Line Voltage Connection (APS-7101).....	20
Power Up.....	23
Output Terminals.....	24
Installing the Optional Hardware Modules	28
Using the Rack Mount Kit	30
How to Use the Instrument	30
Reset to Default Settings	33
View System Version and Serial Number.....	34
LCD Configuration.....	35
Buzzer	36
USB Driver Installation	37
Basic Operation	40
Setting the Voltage Range.....	40
Setting the Voltage Limit	41
Setting the Output Voltage.....	42
Setting the Frequency Limit	43
Setting the Output Frequency.....	44
Setting the Peak Current Limit	45
Setting the Current RMS Level.....	48
Alarm Clear	51
Display Modes	52
Panel Lock.....	54
Turning the Output On	55
Preset Settings	56
Save Preset Settings to Local Memory	56
Load Preset Settings to Local Memory	57
Manage Preset Settings.....	58
Test Mode Function	60
Test Mode Overview.....	61
Test Settings.....	63
Save a Test to Local Memory.....	65
Recall a Test from Local Memory.....	65
Manage Test Settings.....	66

Running a Test 68

Set Up

Line Voltage Connection (APS-7101)

Background The APS-7101 is equipped with an input power terminal that can accept 115V/230V \pm 15%. To connect or replace the power cord (GW Instek part number: APS-7101: 4300-31000101, use the procedure below:




The following procedure should only be attempted by competent persons.

Ensure the AC power cord is not connected to power.

Removal


1. Turn off the power switch.




APS-7101

2. Unscrew the power cord strain relief on the rear output socket.
3. Remove the 2 screws holding the power cord cover and remove.

APS-7101



4. Remove the AC power cord wires.




 **CAUTION**

The power line inputs for the APS-7101 are on the outer cluster of terminals.


The terminals to the inner of the panel are the rear panel outputs.

Installation

1. Connect the AC power cord wires to the AC input terminals.
 - White/Blue → Neutral (N)
 - Green/Green-yellow → GND (⊕)
 - Black/Brown → Line (L)




2. Re-install the power cord cover.
3. Screw the power cord strain relief back onto the cover.



Power Up


Steps

4. Socket type: Connect the power cord to the rear panel socket.



Input Power Terminal: Page 20
Connect the power cord to the input power terminals.

5. Press the POWER key. The splash screen will appear momentarily before the continuous mode screen appears with the settings loaded.



CAUTION

The power supply takes around 10 seconds to fully turn on and shutdown.

Do not turn the power on and off quickly.

Output Terminals

Background The output terminals can be output from either the front panel or from the rear panel. The outputs are limited to 2.5A/1.25A/0.63A (APS-7051) or 5A/2.5A/1.25A (APS-7101).

Supported plugs Multi-region terminal Socket
Supported Standards:


- IEC, North America, Japan.



Dangerous voltages. Ensure that the power to the instrument is disabled before handling the power supply output terminals. Failing to do so may lead to electric shock.

**Front Panel
Output
Connection**

1. The front panel has a multi-region power socket depending on the socket type.
2. Insert the plug from the DUT into the socket.




3. Turn the power on. The AC power supply is now ready to power the DUT.

Rear Panel Output Connection


The rear panel output is used to supply higher power DUTs. The rear panel output connection is similar to the universal rear panel line input connection on the APS-7101.

1. Disconnect the unit from the mains power socket and turn the power switch off.
2. Unscrew the power cord strain relief.
3. Remove the 2 screws holding the power cord cover and remove.

APS-7051




APS-7101



For the APS-7101, there is a single bank for the input and output terminals. Ensure the correct terminals are connected. The APS-7051 only has a single bank of output terminals on the rear panel.

Installation


4. Connect the output AC power cord wires to the output terminals.
 - Black → Neutral (N)
 - Green → GND (\perp)
 - Red → Line (L)




APS-7101 shown. The input terminals are already connected and shows which output terminals are to be connected.

5. Re-install the power cord cover.
6. Screw the power cord strain relief back onto the power cord cover.

APS-7101



APS-7051



7. Turn the power on. The AC power supply is now ready to power the DUT.

Installing the Optional Hardware Modules


Background There are a number of optional modules that can be installed for remote control.

Optional Modules APS-001 GPIB Interface card
 APS-002 RS-232/USB CDC interface card


 **WARNING** Dangerous voltages. Ensure that the power to the instrument is disabled before handling the power supply output terminals. Failing to do so may lead to electric shock.

 **CAUTION** Ensure the power is off before installing any of the optional modules.

Installation 1. Turn off the power switch.




2. Unscrew the two screws holding the options panel plate.



APS-7101 shown

3. Slide the module PCB onto the rails on the inside of the module slot.
4. Secure the module with the screws that were removed from step 2.



APS-7101 shown


5. The module will be recognized upon startup.

Using the Rack Mount Kit

Background

The APS-7000 series has an optional Rack Mount Kit (GW Instek part number: GRA-423). The APS-7051 and APS-7101 are designed to fit into a 2U rack height. Please see your distributor for further rack mount details.

Rack mount diagram



CAUTION

Ensure adequate ventilation is provided when using the rack mount. Ensure that a gap of at least 50mm is given for the side air intakes. Failure to do so may cause the instrument to overheat.

How to Use the Instrument

Background


The APS-7000 AC power supplies generally use the scroll wheel, arrow keys and Enter keys to edit numerical values or to select menu options.

Menu navigation is performed using the menu keys and function keys on the front panel.

The following section will explain some of these concepts in detail.

Selecting Menu Items

1. Turn the scroll wheel to select parameters in menus and lists. The selected parameter will be highlighted in orange. The scroll wheel is also used to increment/decrement setting values.




2. Press the Enter key to edit the parameter or to enter the selected menu.



Example

Selected parameter




The following is an example of the menu list that appears when the Menu key is pressed.

Using the Keypad to edit parameter values

When editing a value the keypad can be used to directly enter the desired value.

1. Type the value of the parameter using the keypad.




2. Press the Enter key to confirm the edit.



Example



Parameter



Using the Arrow Keys and Scroll wheel to edit parameter values

Use the arrow keys to select a digit power and then use the scroll wheel to edit the value by that power.

1. Use the arrow keys to move the cursor to the digit of the desired power.
2. Turn the scroll wheel to edit the value by the resolution of the selected digit.



3. Repeat the steps above for all the relevant digits.
4. Press the Enter key to confirm the edit.






Note

By default the cursor starts at the lowest power digit.

Using the
Function Keys

The function keys (F1 ~ F4) are quick settings keys, the function of which depends on the current menu or operation.

1. Press the function key that corresponds to the setting directly to its left.
2. The setting or parameter is immediately executed.



3. Repeat the steps above for all the relevant digits.

Reset to Default Settings

Background

The default settings can be restored from the Menu key settings. See page 94 for the default factory settings.

Steps

1. Press the *Menu* key. The Menu settings will appear on the display.



- Use the scroll wheel to go to item 8, *Default Setting*.
- Press *Enter* x2 to restore the default settings.



Default settings

View System Version and Serial Number

Background


The Menu>System Information setting displays the serial number and version number.

Steps

- Press the Menu key. The Menu setting will appear on the display. 
- The system information should now be listed on the display.

If not, use the scroll wheel to go to item 1, *System Information*.

System Information




LCD Configuration

Background The LCD Configuration setting sets the brightness, contrast and saturation level of the LCD display.

- Steps**
1. Press the *Menu* key. The Menu settings will appear on the display. 
 2. Use the scroll wheel to go to item 7, *LCD Configuration* and press *Enter*.
 3. Set the brightness, contrast and saturation.
 - Contrast(%) 1 ~ 100% (Default=50%)
 - Brightness(%) 1 ~ 100% (Default=50%)
 - Saturation(%) 1 ~ 100% (Default=50%)

- Exit**
4. Press *Exit*[F4] to exit from the Ramp Control settings. 

- Default Settings**
5. Press *Default*[F3] to set all the LCD settings to 50%.



Default settings

LCD settings

Buzzer

The Buzzer setting turns the buzzer sound on or off for key presses and alarms.

Steps


1. Press the *Menu* key. The Menu setting will appear on the display. 
2. Use the scroll wheel to go to item 2, *MISC Configuration* and press *Enter*.
3. Go to the *Buzzer* setting using the scroll wheel and press *Enter*. Turn the setting on or off and press *Enter* again to confirm.

Buzzer ON, OFF

Exit

4. Press *Exit[F4]* to exit from the MISC Configuration settings. 

Example



Settings

USB Driver Installation

Background If the USB Type B interface is to be used for remote control, the USB driver needs to be installed.

 **Note** The USB driver, GW_APS.inf, is located on the CD Rom that accompanied this user manual. Alternatively the driver can be downloaded from the GW Instek website.

For information on the USB interface, see page 71.

Steps


1. Connect the rear panel USB -B port on the APS-7000 to the PC using a USB Type A to B cable.

2. Go the Windows Device Manager.


For Windows 7:

Start > Control Panel > Hardware and Sound > Device Manager


3. The APS-7000 will be located under *Other Devices* in the hardware tree. Right-click the APS-7XXX and choose *Update Driver Software*.



- From the hardware wizard choose *Browse my computer driver software*.



- Set the file path to the location of the USB driver, click Next and finish the driver installation.



6. In APS-7000 will now be located in the *Ports* node of the hardware tree in the Windows Device Manager if the driver installation was successful.



Basic Operation

This section describes the basic operations required to operate the power supply.

- Setting the Voltage Range → from page 40
- Setting the Voltage Limit → from page 41
- Setting the Output Voltage → from page 42
- Setting the Frequency Limit → page 43
- Setting the Output Frequency → page 44
- Setting the Peak Current Limit → from page 45
- Setting the Current RMS Level → from page 48
- Clearing the Alarm → from page 51
- Setting the Display mode → from page 52
- Panel lock → from page 54
- Turning the Output on/off → from page 55

Before operating the power supply, please see the Getting Started chapter, page 8.


Setting the Voltage Range

Background	The Range setting determines the general outlet voltage range. The ranges available correspond to common mains output voltage standards.
------------	--

- | | |
|-------|--|
| Steps | 1. Press Range to access the Range menu.  |
| | 2. Set the voltage range with the scroll wheel or with the F1 ~ F4 soft-keys. |
-

Range	AUTO, 1000V, 500V, 250V
-------	-------------------------

- | | |
|--|--|
| | 3. Press Enter to confirm the Range setting. |
|--|--|
-



Note


If the range is changed from 250V to 1000V, the Irms and IPK values will automatically be changed to a lower value. If the range is changed from 1000V to 250V, the Irms and IPK values remain the same.

If the voltage range is changed when the output is on, the output will be automatically turned off.

Setting the Voltage Limit

Background Setting the voltage limit allows the output voltage to be set to any level within the voltage limit (V Limit) range.

Steps 1. Press *Shift* + *V* to access the Volt Limit menu.




2. Set the voltage limit with the scroll wheel or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the limit to the maximum and minimum, respectively.

Range	10% of full range ~ full range
-------	--------------------------------

Soft-keys	MAX, MIN
-----------	----------

3. Press *Enter* to confirm the voltage limit setting.



Note

Each voltage range (250V, 500V, 1000V) has an independent voltage limit.

Setting the Output Voltage

Background

The voltage setting sets the voltage level of the power supply.



Note

Before setting the power supply voltage level, set the voltage range and voltage limit.

Steps

1. Press the V key. The ACV parameter will be editable.



2. Set the voltage with the scroll wheel/keypad or with the F1 ~ F4 soft-keys.

Range 0 volts ~ full range

Soft-keys DEF1, DEF2, MAX, MIN

3. Press *Enter* to confirm the voltage setting.

Preset Settings

The DEF1 and DEF2 preset settings are user defined settings. By default they are set to 0.00 volts. The MAX and MIN soft-keys set the voltage to the maximum and minimum, respectively.

4. Press the *V* key and set the desired voltage with the scroll wheel/keypad.

Range 0 volts ~ full scale of voltage range

5. Press and hold the DEF1 or DEF2 soft-key until “Saved to DEF1/2” is displayed. This will save the voltage setting to the DEF1 or DEF2 soft-key.



Note

Trying to set the voltage outside of the voltage limit/range will result in a voltage setting error being displayed on the screen.

The voltage level can be set when the output is on.

Example

Voltage setting	Preset voltage settings								
	<table border="0"> <tr> <td style="text-align: center;">DEF1 0.00</td> <td style="padding-left: 10px;">F1</td> </tr> <tr> <td style="text-align: center;">DEF2 0.00</td> <td style="padding-left: 10px;">F2</td> </tr> <tr> <td style="text-align: center;">MAX</td> <td style="padding-left: 10px;">F3</td> </tr> <tr> <td style="text-align: center;">MIN</td> <td style="padding-left: 10px;">F4</td> </tr> </table>	DEF1 0.00	F1	DEF2 0.00	F2	MAX	F3	MIN	F4
DEF1 0.00	F1								
DEF2 0.00	F2								
MAX	F3								
MIN	F4								


Setting the Frequency Limit

Background

Setting the frequency limit allows the frequency output to be set to any level within the limit range.

Steps

1. Press *Shift + F* to access the Freq Limit menu.




- Set the frequency limit with the scroll wheel/keypad or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the frequency limit to the maximum and minimum, respectively.

Range	45.00 ~ 500.0Hz
-------	-----------------

Soft-keys	MAX, MIN
-----------	----------

- Press *Enter* to confirm the limit setting.

Example



Setting the Output Frequency

The frequency setting sets the frequency of the output.

Background	Before setting the frequency, set the frequency limit.
------------	--

Steps

- Press the *F* key. The **FREQ** parameter will be editable.



- Set the frequency with the scroll wheel/keypad or with the F1 ~ F4 soft-keys.

Range	45.00 ~ 500.0Hz
-------	-----------------

Soft-keys	DEF1, DEF2, MAX, MIN
-----------	----------------------

- Press *Enter* to confirm the frequency setting.


Preset Settings The DEF1 and DEF2 preset settings are user defined settings. By default they are set to 50.00Hz and 60.00Hz, respectively. The MAX and MIN soft-keys set the frequency to the maximum and minimum, respectively.

4. Press the *F* key and set the desired frequency with the scroll wheel/keypad.

Range 45.00 ~ 500.0Hz

5. Press and hold the DEF1 or DEF2 soft-key until “Saved to DEF1/2” is displayed. This will save the frequency setting to the DEF1 or DEF2 soft-key.
-

Example



 **Note**

Trying to set the frequency outside of the frequency limit will result in a frequency setting error being displayed on the screen.

The frequency can be set when the output is on.

Setting the Peak Current Limit

Background Setting the peak current limit sets a limit on the current that can be sourced by the power supply.




Note

When the peak current limit is tripped, an alarm will sound. Press Shift + 9 to clear the I_{pk} alarm.

Shift+6 can also clear the I_{pk} alarm. See page 51 for details.

Steps

1. Press *Shift* + *I rms* to access the I_{peak} menu.



2. Set the peak current with the scroll wheel/keypad or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the peak current to the maximum and minimum, respectively.

Range 10% ~ 100% peak current value. The peak current value depends on the selected voltage range.

Soft-keys MAX, MIN

3. Press *Enter* to confirm the peak current setting.


Example

I_{peak}

Min/Max settings
F3
F4

Delay Time Settings

The Delay Time setting essentially defines how long the measurement of the peak current must be sustained for before it is recognized. By default the delay time is turned off.




1. Press *Shift + I rms* and then press *DELAY[F2]*.
2. Set the desired delay time with the scroll wheel/keypad or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the delay time to the maximum and minimum, respectively.

Range 0(off) ~ 10 seconds

Soft-keys MAX, MIN

3. Press *Enter* to confirm the delay time setting.

Example



IPK Measurement Range Settings


The IPK Range settings allow you to manually set the peak current measurement range. By default this setting is set to AUTO.

1. Press Shift + I rms and then press IPK Range[F1].
2. Set the desired range with the scroll wheel.

Range	AUTO, 0.28A, 1.4A, 14A, 70A
-------	-----------------------------
3. Press Enter to confirm the IPK Range setting.

Example

IPK Range settings




Setting the Current RMS Level

Background	The I rms setting sets the root mean square current.
------------	--

- | | | | | | |
|-----------|---|-------|--|-----------|----------|
| Steps | <ol style="list-style-type: none"> 1. Press <i>I rms</i> to access the I rms menu. I rms 2. Set the I rms level with the scroll wheel/keypad or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the I rms level to the maximum and minimum, respectively. <table border="1" style="margin-left: 40px; border-collapse: collapse;"> <tr> <td style="padding: 2px;">Range</td> <td style="padding: 2px;">0.00 ~ full scale A (dependant on the voltage range)</td> </tr> <tr> <td style="padding: 2px;">Soft-keys</td> <td style="padding: 2px;">MAX, MIN</td> </tr> </table> 3. Press Enter to confirm the current setting. | Range | 0.00 ~ full scale A (dependant on the voltage range) | Soft-keys | MAX, MIN |
| Range | 0.00 ~ full scale A (dependant on the voltage range) | | | | |
| Soft-keys | MAX, MIN | | | | |

Example




Note

Setting the I_{rms} level to 0.00 will disable OCP.

Setting I_{rms} to 0A is dangerous.

I_{rms} Delay Time Settings

The Delay Time setting defines how long the I_{rms} measurement must be sustained for before it is recognized. By default the I_{rms} delay time is turned off.




4. Press I_{rms} and then press $DELAY[F2]$.
5. Set the desired delay time with the scroll wheel/keypad or with the F3 ~ F4 soft-keys. The MAX and MIN soft-keys set the delay time to the maximum and minimum, respectively.

Range 0(off) ~ 10 seconds

Soft-keys MAX, MIN

6. Press *Enter* to confirm the delay time setting.

Example




OC Fold Settings

The over current fold back settings allow the APS-7000 to work as either a constant voltage source or a constant current source.

While the unit is sourcing less current than the Irms current limit, the APS-7000 will act as a constant voltage source. In this mode, the voltage level will remain constant while the current level may vary. This is the normal operating mode.

When the current level reaches the Irms limit, the APS-7000 will act as a constant current source. In this mode the current is constant and the voltage level varies. When the current subsides below the Irms limit again, the unit will again act as a constant voltage source. When OC Fold is turned off, the APS-7000 will act as a current limiting power source when the Irms limit has been reached.






Note

OC-FOLD can only be active when the I_{rms} level is greater than 0.

7. Press I_{rms} and then press **OC-FOLD[F1]** toggle the OC-Fold function on or off.

OC-Fold setting




Alarm Clear


Background The ALM CLR (Alarm Clear) function will clear any Over Power, Over Irms, Over Ipeak and Over Temperature alarms.

Applicable Alarms OVER POWER, OVER IRMS, OVER IPEAK, OVER TEMPERATURE

- Steps**
1. Press *Shift* + 6 to clear any alarms.



Example



Display Modes


The APS-7000 power supply has two display modes. The standard display mode shows the power supply setup on the left and the 3 configurable measurements on the right. The simple display mode shows all measurement items available on the APS-7000.

Steps

1. Press the *Display* key.
2. The display mode will toggle each time the key is pressed.




Standard Mode



Simple Mode

Measurement Items




Configuring the Standard Mode Measurements

1. Press the *Meas Item1, Item2 or Item3* soft-key.



2. Use the scroll wheel to select a measurement item and press Enter to confirm.

Sets third measurement item to frequency



Hold Measurement

The Hold function will “hold” the current measurements on the display. Measurements won’t be updated on the display until the function is released.

Press *HOLD[F4]* to toggle hold on or off.

Panel Lock

The panel lock feature prevents settings from being changed accidentally. When activated, all keys and knobs except the Lock/Unlock key and the Output key (if active) will be disabled.

Activate the panel lock

Press the *Lock* key to activate the panel lock. "Keys locked" appears on the display.



A lock icon will appear in the top corner when the panel keys are locked.




Disable the panel lock

Hold the *Lock* key for ~3 seconds to disable the panel lock. "Keys unlocked" will appear on the display and the padlock icon will disappear.



Example



Turning the Output On

When the output is turned on, the DUT can be connected to either the rear panel output or the front panel output.



Both of these outputs are electrically linked. Only one DUT should be connected to any one of the outputs at a time. Using both outputs at the same time is not supported. Using the front and rear outputs at the same time could cause dangerous operating conditions. See page 24 for details about using the output terminals or sockets.

Turn Output On

Press the *Output* key. The Output key will light up and ON will be displayed in the status bar to indicate that the output is on.



Turn Output Off

Press the *Output* key. The Output key light will go out and OFF will be displayed in the status bar to indicate that the output is off.



Preset Settings

- Save Presets to Local Memory → from page 56
- Recall Presets to Local Memory → from page 57
- Manage Preset Settings → from page 58

Save Preset Settings to Local Memory

Up to 10 preset settings can be saved to internal memory.

- Steps
1. Press *Preset* and then hold a  *number key (0~9)* to save the present settings to the corresponding memory number.  +  (hold)

Presets	M0 ~ M9
---------	---------

2. Press the *Preset* key again to exit from the preset mode.
-

Example For example, pressing *Preset* & holding 1 will save the present settings to memory slot 1 (saved to M1).




Note

The preset key will become green when active. A beep will be heard (Buzzer set to ON) and a message will displayed when the settings are saved.

Load Preset Settings to Local Memory

Any of the 10 preset settings can be recalled from internal memory.

- Steps
1. Press *Preset* and press a *number key*(0~9) to load the corresponding memory number.



Presets	M0 ~ M9
---------	---------
 2. Press the *Preset* key again to exit from the preset mode.

Example

For example, pressing *Preset* + 1 will recall the saved settings from memory slot 1 (recalled from M1).



The preset key will become green when active. A beep will be heard (Buzzer set to ON) and a message will be displayed when the settings are recalled.

Manage Preset Settings

Preset settings can be easily saved to or from a USB flash drive using the Save/Recall Files utility in the Menu system. Files can also be deleted from local memory using the utility.

File Format	<p>When files are saved to USB they are saved in the following format: presetX.set, where X is the memory number M0 ~ M9. The files are saved to USB:/gw.</p> <p>When files are recalled from USB, files must be recalled from the same memory number. For example, the file preset0.set can only be recalled to memory number M0. The files can only be recalled from the USB:/gw directory.</p>						
Steps	<ol style="list-style-type: none"> 1. Press the <i>Menu</i> key. The Menu settings will appear on the display.  2. Use the scroll wheel to go to item 10, <i>Save/Recall Files</i> and press <i>Enter</i>. 3. Go to the <i>Type</i> setting using the scroll wheel and press <i>Enter</i>. Select <i>Preset</i> and press <i>Enter</i> to confirm. 4. Go to the <i>Action</i> setting and choose the file operation and then press <i>Enter</i>. <hr/> <table border="0" style="width: 100%;"> <tr> <td style="padding-right: 20px;">MEM→USB</td> <td>Saves the selected preset memory from the local memory to a USB flash drive.</td> </tr> <tr> <td colspan="2"><hr/></td> </tr> <tr> <td style="padding-right: 20px;">MEM←USB</td> <td>Loads a preset memory from a USB flash drive to the selected local memory.</td> </tr> </table> <hr/>	MEM→USB	Saves the selected preset memory from the local memory to a USB flash drive.	<hr/>		MEM←USB	Loads a preset memory from a USB flash drive to the selected local memory.
MEM→USB	Saves the selected preset memory from the local memory to a USB flash drive.						
<hr/>							
MEM←USB	Loads a preset memory from a USB flash drive to the selected local memory.						

DELETE(MEM) Deletes the selected preset memory from local memory.

5. Go to the *Memory No.* setting and select the preset memory number to perform the operation on. Press *Enter* to confirm.

Memory No. 0 ~ 9 (M0 ~ M9)

Execute File Operation

6. Press *Exe[F1]* to perform the file operation.



Exit

7. Press *Exit[F4]* to exit from the *Save/Recall Files* settings.



Example



Settings

Test Mode Function

The Test Mode function is a quick and easy way to simulate fluctuations in voltage and frequency in mains supply power.

- Test Mode Overview → from page 61
- Test Settings → from page 63
- Manage Test Settings → from page 66
- Run Test → from page 68

Test Mode Overview

Background The Test function is used to test power supply fluctuation. This function is able to simulate common abnormalities in mains power such as fluctuations in voltage and frequency. These tests can be run as one-off anomalies or cyclic anomalies.

Setting Screen Overview

Number of repetitions

V RANGE

TEST

LO HI AUTO

Init Normal1 Trans1 Abnormal Trans2 Normal2 Init

Step	Initial	Repeat
Time	0.10 s	
Vset	0.00	
Fset	50.00	

Recall None Recall test

Save None Save test

RUN Run test

Step time

Step

Step voltage

Step frequency


Step Overview

The Test function is comprised of 6 steps. Each step is run sequentially in the following order: Initial, Normal1, Trans1, Abnormal, Trans2, Normal2, Initial.

Initial The Initial step is used as the initial and final settings of the waveform test. This is the standby step before the test starts and the standby step after the test ends.

Normal1 This step configures the normal output conditions that precede the abnormal conditions.

Trans1	This step configures the transition from normal to abnormal conditions. This step will linearly interpolate the normal settings to the abnormal settings. This step can be skipped for abrupt state changes.
Abnormal	This step contains the abnormal conditions for the test.
Trans2	This step configures the transition from abnormal to normal conditions.
Normal2	This step configures the normal conditions that supersede the abnormal conditions.



Parameter Overview

The following table shows which parameters are available for each step.



Step\Parameter	Initial	Normal1	Trans1	Abnormal	Trans2	Normal2
Repeat	✓	✓	✓	✓	✓	✓
Time	✓	✓	✓	✓	✓	✓
Vset	✓	✓	X	✓	X	✓
Fset	✓	✓	X	✓	X	✓

Repeat	Indicates the number of times the test will be run, from Normal1 to Normal2. A value of 0 indicates infinite repeats. The repeat setting is the same for each step.
Time	Sets the duration time of the step.

Fset	Sets the frequency of the step. Not applicable for the Trans 1/2 steps.
Vset	Sets the voltage of the step. Not applicable for the Trans 1/2 steps.

Test Settings

Entering the Test Menu 1. Press *Test*.



- Steps
- Use the scroll wheel to go to the *Step* setting and press *Enter*.
 - Use the scroll wheel to select one of the test steps and press *Enter*.

Steps	Initial, Normal1, Trans1, Abnormal, Trans2, Normal2
-------	---

- Go to the *Time* setting and set the duration of the step.

Time	0.01 ~ 99.99s, 0(Trans 1 and Trans2) Note: For Trans1 and Trans2, it supports a value of 0, which will skip the step.
------	--

5. Press the *Range* key repeatedly to set the voltage range for the *Vset* parameter. The range will be shown in the top corner, which indicates that the test will be executed within this voltage range.

Range



Range LO(250V), MD(500V), HI(1000V), Auto

6. Go to the *Vset* setting and set the *Vrms* level of the step. If you input a *Vset* value that is not within the voltage range, the input value will be ignored.

Not applicable for Trans1 and Trans2.

Vset 0.00 ~ 1000Vrms (range dependent), Auto

7. Go to the *Fset* setting set the frequency of the step. Not applicable for Trans1 and Trans2.

Fset 45.00 ~ 500.0Hz

8. Lastly, go to the *Repeat* parameter to select the number of times the test will repeat the Normal1-Trans1-Abnormal-Trans2-Normal2 sequence of steps. A value of 0 will set the number of repetitions to infinite.

Repeat 1 ~ 9999, 0(infinite)

Save a Test to Local Memory

Saving a Test Test settings can be saved to one of 10 memory slots (TEST0 ~ TEST9).

- Steps**
1. Press *Save*[F3] and then long press a *number key* when prompted.
 2. A message will appear when the save is successful.

Save	TEST0 ~ TEST9
------	---------------

Recall a Test from Local Memory

Recall a Test Test settings can be recalled from one of 10 memory slots (TEST0 ~ TEST9).

- Steps**
1. Press *Recall*[F2] and then press a *number key* when prompted.
 2. A message will appear when the settings are recalled successfully.

Recall	TEST0 ~ TEST9
--------	---------------

Manage Test Settings

Test settings can be easily saved to or from a USB flash drive using the Save/Recall Files utility in the Menu system. Files can also be deleted from local memory using the utility.

File Format When files are saved to USB they are saved in the following format:
testX.sim, where X is the memory number 0 ~ 9 (TEST0 ~ TEST9). The files are saved to USB:/gw.

When files are recalled from USB, files must be recalled from the same memory number. For example, the file test0.sim can only be recalled to memory number TEST0. The files can only be recalled from the USB:/gw directory.

- Steps**
1. Press the *Menu* key. The Menu settings will appear on the display. 
 2. Use the scroll wheel to go to item 10, *Save/Recall Files* and press *Enter*.
 3. Go to the *Type* setting using the scroll wheel and press *Enter*. Select *TEST* and press *Enter* to confirm.
 4. Go to the *Action* setting and choose the file operation and then press *Enter*.

MEM→USB Saves the selected test memory from the local memory to a USB flash drive.

MEM←USB Loads the test memory from a USB flash drive to the selected local memory.

DELETE(MEM) Deletes the selected test memory from local memory.

- Go to the *Memory No.* setting and select the test memory number to perform the operation on. Press *Enter* to confirm.

Memory No. 0 ~ 9 (TEST0 ~ TEST9)

Execute File Operation

- Press *Exe[F1]* to perform the file operation.




Exit

- Press *Exit[F4]* to exit from the *Save/Recall Files* settings.



Example



Settings

Running a Test

Background When running a test, the display changes to the run test view.

Run Screen Overview

The screenshot shows a 'Settings' screen with the following elements:

- TEST** label at the top left.
- 0 / 5** at the top right, indicating the current step.
- VSET** field showing 110.0 V.
- FREQ.** field showing 50.00 Hz.
- Measurement readouts: 110.0 V, 0.00 W, 0.00 mA, 0.000 PF, 50.00 Hz, and 0.0 Ap.
- HOLD** button (orange) labeled 'Hold/Conti test'.
- STOP** button (yellow) labeled 'Stop/Run test'.
- Text 'Step X of Y' to the right of the screen.
- An arrow points from the text 'Readback measurements' below to the measurement readouts.

Steps 1. Press *Output*.



2. Press *Run[F4]*. The test will start to run.

The settings of the current step will be shown at the top of the screen and the measurement readout will be shown on the bottom of the screen.

The top-right of the screen will display the current step number of the test.

1/5 = Normal1	2/5 = Trans1
3/5 = Abnormal	4/5 = Trans2
5/5 = Normal2	

3. The test will continue to run until the last repeat step has run, *Stop[F4]* is pressed or the output is turned off*. When the test has finished/stopped, the screen will return to the original settings screen.

Hold Test To pause the test mid-way, press *Hold*[F3].

Continue Test To continue a paused test, press *Conti*[F3].

C OMMUNICATION

I NTERFACE

This chapter describes basic configuration of IEEE488.2 based remote control. For a command list, refer to the programming manual, downloadable from GW Instek website, www.gwinstek.com



Note

If the instrument is remotely controlled via the USB/LAN/RS-232/GPIB interface, the panel lock is automatically enabled.

Interface Configuration.....	71
USB Remote Interface – Optional.....	71
RS-232 Remote Interface - Optional.....	72
RS-232/USB Remote Control Function Check.....	74
Using Realterm to Establish a Remote Connection	75
Configure GPIB Interface - Optional.....	78
GPIB Function Check	79
Configure Ethernet Connection.....	82
Web Server Remote Control Function Check.....	84
Socket Server Function Check.....	85

Interface Configuration

USB Remote Interface – Optional

USB configuration	PC side connector	Type A, host
	APS-7000 side connector	Rear panel Type B, slave
	Speed	1.1/2.0 (full speed/auto speed)
	USB Class	CDC (communications device class)



Note

The RS-232/USB interface card (APS-002) must first be installed before the USB interface can be used for remote control. Please see page 28 for installation details.

Steps


1. Connect the Type A-Type B USB cable from the PC to the rear panel USB B port. 
2. Press the *Menu* key. The Menu setting will appear on the display. 
3. Use the scroll wheel to go to item 3, *Rear USB* and press *Enter*.

4. Go to the *Speed* setting and set the USB speed.

Speed	Full, Auto
-------	------------

5. If the connection is successful *Connection Status* will change from Offline to Online.

Connection status



Exit

6. Press *Exit*[F4] to exit from the rear panel USB settings.




RS-232 Remote Interface - Optional

The APS-002 RS-232/USB interface card must be installed to remotely control the APS-7000 via the serial port.

RS-232 configuration	Connector	BD-9, male
	Parameters	Baud rate, data bits, parity, stop bits.


Pin Assignment



- 2: RxD (Receive data)
 - 3: TxD (Transmit data)
 - 5: GND
 - 4, 6 ~ 9: No connection
-

Pin Connection

Use a Null Modem connection (RS-232C cable) as shown in the diagram below.






Note

The RS-232/USB (APS-002) or RS-232 (APS-007) must first be installed before the RS-232 interface can be used for remote control. Please see page 28 for installation details.

Steps


1. Connect the RS-232C cable from the PC to the rear panel RS-232 port. 
2. Press the *Menu* key. The Menu setting will appear on the display. 
3. Use the scroll wheel to go to item 5, *Serial Port* and press *Enter*.
4. Go to the *Function Active* setting and turn the serial port connection on.

Function Active	ON, OFF
-----------------	---------

5. Set the remaining serial port settings.

Baud rate	1200, 2400, 4800, 9600(default), 19200, 38400, 57600, 115200,
Data bits	7, 8(default)
Parity	None(default), odd, even
Stop bits	1(default),2

Serial port configuration



Exit

6. Press *Exit*[F4] to exit from the serial port settings.



RS-232/USB Remote Control Function Check

Functionality
check

Invoke a terminal application such as Realterm.

For both USB and RS-232, set the COM port, baud rate, stop bit, data bit and parity accordingly. The RS-232 settings are configured on the APS-7000. The UART settings for the USB connection can be seen in the Windows Device Manager.

To check the COM settings in Windows, see the Device Manager. For example, in WinXP go to the Control panel → System → Hardware tab.



Note

If you are not familiar with using a terminal application to send/receive remote commands from the serial port or via a USB connection, please see page 75 for more information.

Run this query command via the terminal after the instrument has been configured for RS-232/USB remote control (page 72, 71).

*IDN?

This should return the Manufacturer, Model number, Serial number, and Software version in the following format.

```
GWINSTEK,APS-7051, GEXXXXXXX,  
XX.XX.XXXXXXX
```

```
Manufacturer: GWINSTEK  
Model number : APS-7051
```

Serial number : GEXXXXXXX

Software version : XX.XX.XXXXXXXX



Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

Using Realterm to Establish a Remote Connection

Background

Realterm is a terminal program that can be used to communicate with a device attached to the serial port of a PC or via an emulated serial port via USB.

The following instructions apply to version 2.0.0.70. Even though Realterm is used as an example to establish a remote connection, any terminal program can be used that has similar functionality.



Note

Realterm can be downloaded on Sourceforge.net free of charge.

For more information please see <http://realterm.sourceforge.net/>


Operation

1. Download Realterm and install according to the instructions on the Realterm website.
2. Connect the APS-7000 via USB (page 71) or via RS-232 (page 72).
3. If using RS-232, make note of the configured baud rate, stop bits and parity.
4. Go to the Windows device manager and find the COM port number for the connection. For example, go to the Start menu > Control

Panel > Device Manager.

Double click the *Ports* icon to reveal the connected serial port devices and the COM port for the each connected device.

If using USB, the baud rate, stop bit and parity settings can be viewed by right-clicking the connected device and selecting the *Properties* option.



5. Start Realterm on the PC as an administrator.
Click:
Start menu>All Programs>RealTerm>realterm


Tip: to run as an administrator, you can right click the Realterm icon in the Windows Start menu and select the *Run as Administrator* option.

6. After Realterm has started, click on the *Port* tab.

Enter the *Baud*, *Parity*, *Data bits*, *Stop bits* and *Port* number configuration for the connection.

The *Hardware Flow Control*, *Software Flow Control* options can be left at the default settings.

Press *Open* to connect to the APS-7000.



Note

For USB, the baud rate should be fixed to 115,200.


7. Click on the *Send* tab.

In the *EOL* configuration, check on the *+LF* check boxes.

Enter the query:

**idn?*

Click on *Send ASCII*.



- The terminal display will return the following:

*GWINSTEK,APS-7051, GEXXXXXXX,
XX.XX.XXXXXXXX*

(manufacturer, model, serial number, software version)

- If Realterm fails to connect to the APS-7000, please check all the cables and settings and try again.

Configure GPIB Interface - Optional

To use GPIB, the optional APS-001 GPIB interface card must first be installed.




Note

The GPIB interface card (APS-001) must first be installed before the GPIB interface can be used for remote control. Please see page 28 for installation details.

GPIB Configuration

- Connect a GPIB cable from the PC to the GPIB on the interface card.



- Press the *Menu* key. The Menu setting will appear on the display.




- Use the scroll wheel to go to item 6, *GPIB* and press *Enter*.
- If the GPIB card is installed successfully, the *Card Status* will show *Plugged in*.
- Go to the *Function Active* setting and turn the GPIB port on.

Function Active ON, OFF

6. Set the GPIB address.

GPIB Address 0 ~ 30

GPIB port configuration



Exit

7. Press *Exit*[F4] to exit from the serial port settings.



GPIB constraints

- Maximum 15 devices altogether, 20m cable length, 2m between each device
- Unique address assigned to each device
- At least 2/3 of the devices turned On
- No loop or parallel connection

GPIB Function Check

Functionality check

Please use the National Instruments Measurement & Automation Controller software to confirm GPIB/LAN functionality.

See the National Instrument website, <http://www.ni.com> for details.

 Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

Operation


1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:




Start>All Programs>NI MAX



2. From the Configuration panel access; *My System>Devices and Interfaces>GPIB0*
3. Press the *Scan for Instruments* button.
4. In the *Connected Instruments* panel the APS-7000 should be detected as *Instrument 0* with the address the same as that configured on the APS-7000.
5. Double click the *Instrument 0* icon.



6. Click on *Visa Properties*.
7. Click on *Open Visa Test Panel*.



8. Click on the *Input/Output* icon.
9. Under the Basic I/O tab, ensure **IDN?* is written in the *Select or Enter Command* text box.
10. Click on the *Query* button to send the **IDN?* query to the instrument.
11. The instrument identification string will be returned to the buffer area:

*GWINSTEK,APS-7051, GEXXXXXXX,
XX.XX.XXXXXXXX*

(manufacturer, model, serial number, software version)



12. The function check is complete.

Configure Ethernet Connection

The Ethernet interface can be configured for a number of different applications. Ethernet can be configured for basic remote control or monitoring using a web server or it can be configured as a socket server.

The APS-7000 supports both DHCP connections so the instrument can be automatically connected to an existing network or alternatively, network settings can be manually configured.

Ethernet Parameters	MAC Address (display only)	DHCP
	IP Address	Subnet Mask
	Gateway	DNS Address
	DNS Server	Socket port fixed at 2268

- Ethernet Configuration
1. Connect a LAN cable from the PC to the Ethernet port on the rear panel. 
 2. Press the *Menu* key. The Menu setting will appear on the display. 
 3. Use the scroll wheel to go to item 3, *LAN* and press *Enter*.
 4. If the LAN cable is installed correctly a connection is active, the *Connection Status* will show *Online*.
 5. To automatically have the network assign an IP address, set DHCP to ON. Otherwise set DHCP to OFF to manually set the Ethernet settings.
- | | |
|------|---------|
| DHCP | ON, OFF |
|------|---------|

- If DHCP was set to OFF, configure the remaining LAN parameters.

IP Address

Subnet Mask

Gateway

DNS Server

LAN configuration



Exit

- Press *Exit*[F4] to exit from the LAN settings.



Web Server Remote Control Function Check

Functionality check

Enter the IP address of the power supply (for example: http:// XXX.XXX.XXX.XXX) in a web browser after the instrument has been configured for LAN(page 82).

The web interface allows you to:

- View the system and information and the network configuration.
- View the analog control pinout.
- View the dimensions of the unit.
- View the operating area

Example:

The screenshot shows the GW INSTEK web interface. At the top, there is the GW INSTEK logo with the tagline "Made to Measure" and navigation links for "Visit Our Site", "Support", and "Contact Us". The main content area is divided into several sections:

- Welcome Page**: A simple text-based section.
- Network Configuration**: A section with a dashed border containing four input fields:
 - IP Address: 172.16.5.125
 - Subnet Mask: 255.255.128.0
 - Gateway: 172.16.0.254
 - DNS: 172.16.1.252
- Analog Control**: A section with a "DHCP State:" label and two radio buttons, "ON" and "OFF", with "OFF" selected.
- Figure of Dimensions**: A section with a "Password:" label and an empty input field.
- Operating Area**: A section with a "Submit" button.

Socket Server Function Check

Background To test the socket server functionality, National Instruments Measurement and Automation Explorer can be used. This program is available on the NI website, www.ni.com, via a search for the VISA Run-time Engine page, or “downloads” at the following URL, <http://www.ni.com/visa/>

Requirements Operating System: Windows XP, 7, 8, 8.1

Functionality check 1. Start the NI Measurement and Automation Explorer (MAX) program. Using Windows, press:


Start>All Programs>NI MAX




2. From the Configuration panel access;

My System>Devices and Interfaces>Network Devices


3. Press *Add New Network Device>Visa TCP/IP Resource...*




4. Select *Manual Entry of Raw Socket* from the popup window.




5. Enter the IP address and the port number of the APS-7000. The port number is fixed at 2268.
6. Double click the Validate button and press *Next*.



7. Next configure the Alias (name) of the APS-7000 connection. In this example the Alias is: APS
8. Click finish.



9. The IP address of the power supply will now appear under Network Devices in the configuration panel. Select this icon now.
10. Press *Open VISA Test Panel*.




11. Click the *Configuration* Icon. Under the *IO Settings* tab check *Enable Termination Character*. The termination character should be set as *Line Feed - \n*.



12. Click the *Input/Output* icon. Under the *Basic I/O* tab, make sure **IDN?\n* is entered in the *Select or Enter Command* drop box.
13. Click *Query*.

The APS-7000 will return the machine identification string into the buffer area:
**GWINSTEK,APS-7051, GEXXXXXXX,
 XX.XX.XXXXXXXX**



 Note

For further details, please see the programming manual, available on the GW Instek web site @ www.gwinstek.com.

FAQ

- The accuracy does not match the specification.
- The display shows “fuse broken” message.
- The display shows “output shorted” message.
- The display shows “waiting for 10secs” message.
- The display shows “OCP” message.

The accuracy does not match the specification.

Make sure the device is powered On for at least 30 minutes, within +18°C~+28°C. This is necessary to stabilize the unit to match the specification.

The display shows “fuse broken” message.

The internal protection fuse is open. Contact your local dealer or GW Instek.

The display shows “output shorted” message.

Make sure the DUT is correctly connected to the APS-7000 output terminals and that no shortcut exist. A DUT malfunction may also be the cause.

The display shows “waiting for 10secs” message.

A protection function is likely in force, check the DUT settings.

The display shows “OCP” message.

OCP message be occurred that is mean over the specification of APS-7000 series.

Even set Irms is equal to 0.

Purchasing more higher power AC Source, please.

For more information, contact your local dealer or GWInstek at www.gwinstek.com / marketing@goodwill.com.tw.

APPENDIX

Firmware Update

Background The APS-7000 firmware can be upgraded using the USB A port on the front panel. See your local distributor or the GW Instek website for the latest firmware information.



Note

- Ensure the DUT is not connected.
 - Ensure the output is off.
-

Steps

1. Insert a USB Flash Drive into the USB port on front panel of the APS-7000.
 - The USB drive should include the “**gw.sbt**” **firmware** file in a directory named “gw”(USB:\gw:).
2. Press the *Menu* key. The Menu setting will appear on the display. 
3. Use the scroll wheel to go to item 9, *Special Function* and press *Enter*.
4. Key in the password when prompted and then press *Enter*.
 - The password is “5004”.
5. Go to Item 1, *Update Main Program* and press *Enter*.

- Exit
6. Wait for the unit to update. Upon completion the unit will automatically reset.
-

Example



Password setting screen

APS-7000 Default Settings

The following default settings are the factory configuration settings for the power supply.

For details on how to return to the factory default settings, see page 33.

Continuous Mode		
	APS-7051	APS-7101
Range		250V
ACV		0.00V
FREQ		60.00Hz
IRMS	2.50A	5.00A
V limit		250.0Vrms
F Limit		500.0Hz
Ipeak Limit	10.00Arms	20.00Arms

Test Mode		
	APS-7051	APS-7101
Step		Initial
Repeat		1
Time		0.10s
Vset		0.00
Fset		50.00
Range		LO

Configuration Menu		
	APS-7051	APS-7101
Buzzer		ON
LCD Contrast		50%
LCD Brightness		50%
LCD Saturation		50%

APS-7000 Specifications

The specifications apply when the APS-7000 is powered on for at least 30 minutes.

APS-7000

Model	APS-7051	APS-7101
AC Input		
Phase	Single Phase	
Voltage	115/230 Vac \pm 15%	
Frequency	50/60Hz	
Max. Current	16A / 8A	32A / 16A
Power Factor	0.7 Typ.	
AC Output		
Power Rating	500 VA	1000 VA
Output Voltage	0 ~ 250 Vrms / 0 ~ 500 Vrms / 0 ~ 1000 Vrms	
Output Frequency	45.00 ~ 500.0 Hz	
Maximum Current (r.m.s) ^{*1}		
0 ~ 250 Vrms	2.5 A	5.0 A
0 ~ 500 Vrms	1.25 A	2.5 A
0 ~ 1000 Vrms	0.63 A	1.25 A
Maximum Current (peak)		
0 ~ 250 Vrms	10.0 A	20.0 A
0 ~ 500 Vrms	5.0 A	10.0 A
0 ~ 1000 Vrms	2.5 A	5.0 A
Phase	Single Phase, Two Wire (1P2W)	
Total harmonic distortion (THD) ^{*2}	\leq 0.5% at 45 ~ 500 Hz (Resistive Load)	
Crest factor	\geq 4	
Line regulation	0.1% (% of full scale)	
Load regulation	0.5% (% of full scale)	
Setting		
Voltage		
Range	0 ~ 250 Vrms, 0 ~ 500 Vrms, 0 ~ 1000 Vrms, Auto	
Resolution	0.01 V at 0.00 ~ 99.99 Vrms 0.1 V at 100.0 ~ 999.9 Vrms	
Accuracy	\pm (0.5% of setting + 2 counts)	
Frequency		
Range	45 ~ 500 Hz	
Resolution	0.01 Hz at 45.00 ~ 99.99 Hz 0.1 Hz at 100.0 ~ 500.0 Hz	

Accuracy	$\pm 0.02\%$ of Setting
Measurement *3	
Voltage (r.m.s)	
Range	0.20 ~ 38.75 Vrms
	38.76 ~ 77.50 Vrms
	77.51 ~ 250.0 Vrms
	250.1 ~ 1000 Vrms
Resolution	0.01 V at 0.00 ~ 99.99 Vrms
	0.1 V at 100.0 ~ 999.9 Vrms
Accuracy *4	$\pm (0.5\%$ of reading + 2 counts)
Frequency	
Range	45 ~ 500 Hz
Resolution	0.01 Hz at 45.00 ~ 99.99 Hz
	0.1 Hz at 100.0 ~ 500.0 Hz
Accuracy	± 0.1 Hz
Current (r.m.s)	
Range	2.00 ~ 70.00 mA
	60.0 ~ 350.0 mA
	0.300 ~ 3.500 A
	3.00 ~ 5.00 A
Resolution	0.01 mA
	0.1 mA
	0.001 A
	0.01 A
Accuracy	$\pm (0.6\%$ of reading + 5 counts), 2.00 ~ 350.0 mA
	$\pm (0.5\%$ of reading + 5 counts), 0.350 ~ 3.500 A
	$\pm (0.5\%$ of reading + 3 counts), 3.500 ~ 5.00 A
Current (peak)	
Resolution	0.1 A
Accuracy	$\pm (1\%$ of reading + 1 count)
Power (W)	
Resolution	0.01 W
	0.1 W
	1 W
Accuracy	$\pm (0.6\%$ of reading + 20counts), 0.20 ~ 99.99 W
	$\pm (0.5\%$ of reading + 20counts), 100.0 ~ 999.9 W
	$\pm (0.5\%$ of reading + 2counts), 1000 ~ 9999 W
Power Factor	
Resolution	0.001
Accuracy	$\pm 2\%$ reading + 2 counts
General	
Number of Preset	10 (0~9 numeric keys)
Protection	OCP, OPP, OHP and Alarm

Environmental Conditions		
Operating temperature range	0 ~ +40 °C	
Storage temperature range	-10 ~ +70 °C	
Operating humidity range	20 ~ 80% RH (no condensation)	
Storage humidity range	80% RH or less (no condensation)	
LCD Display	4.3 inch, 480 (RGB) x 272	
Dimensions (mm)		
W	430	430
H	88	88
D	400	560
Weight	24 Kg	38 Kg
Test Function		
Number of Memories	10 (0~9 numeric keys)	
Step Time Setting Range	0.01 ~ 99.99 S	
Operation within Step	Constant, Keep, Linear Sweep	
Parameters	Output Range, Frequency, Waveform (sine wave only)	
Interface		
Standard	USB Host, LAN	

Product specifications are subject to change without notice.

*1 Maximum output current at working voltage 200Vrms, 400Vrms, 800Vrms


*2 45Hz to 500Hz, 10% or higher of the rated output voltage, the maximum current or lower.

*3 All of measurement accuracy is at 23±5°C.

*4 In the case of 25V to 250V / 50V to 500V / 100V to 1000V sine wave, no load.


APS-7000 Dimensions

APS-7051



Scale = mm

APS-7101



Scale = mm

INDEX

Accessories	11	1000VA models	20
Advanced settings		List of features.....	10
Buzzer.....	36	Load preset to local memory	57
Alarm clear	51	Load preset to USB	58
Buzzer	36	Load test to USB.....	66
Caution symbol	4	Model differences	9
Cleaning the instrument.....	6	Module installation	28
Clear alarm.....	51	OC fold.....	50
Conventions	30	Output on	55
Current RMS	48	Output terminals	24
Default settings.....	94	Peak current limit	45
reset.....	33	Power on/off	
Delay time	47	safety instruction	5
Delete test from memory.....	66	Power up.....	23
Display mode		Preset settings.....	56
operation	52	Rack mount	
Disposal instructions.....	6	description.....	30
EN61010		Remote control	70
measurement category	5	Ethernet.....	82
pollution degree	6	GPIB	78
Environment		LAN.....	82
safety instruction.....	6	RS232.....	72
Ethernet		USB.....	71
interface.....	82	Remote control function check	
Firmware update	92	GPIB	79
Frequency limit.....	43	Realterm.....	75
Frequency output	44	RS-232.....	74
Front panel diagram	12	USB.....	74
Ground		Save preset to local memory.....	56
symbol	4	Save preset to USB.....	58
I rms	48	Save test to USB	66
Ipk measurement range.....	47	Serial number	34
Ipk range.....	47	Service operation	
Ipk-Limit.....	45	about disassembly	5
Irms Delay time	49	contact	91
LCD configuration	35	Socket server function check	85
Line voltage		Specifications.....	95
		System version	

view.....	34	USB driver installation.....	37
Test		Voltage limit.....	41
Overview.....	61	Voltage output level.....	42
Recall.....	65	Voltage range.....	40
Run.....	68	Warning symbol.....	4
Save.....	65	Web server function check.....	84
UK power cord.....	7		
Updating the firmware.....	92		