

Measurement Statistics App

GDS 3000 Series

USER MANUAL

GW INSTEK PART NO.



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will Corporation.

The information in this manual was correct at the time of printing. However, Good Will continues to improve its products and therefore reserves the right to change the specifications, equipment, and maintenance procedures at any time without notice.

**Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.**

Table of Contents

I NSTALL THE SOFTWARE	4
U NINSTALL THE SOFTWARE.....	6
H OW TO USE THE SOFTWARE	8
Select an Auto Measurement.....	8
Open Measurement Statistics	10

INSTALL THE SOFTWARE

Step

1. Make sure the firmware version is V1.21 or higher for the GDS-3000 or V1.03 or higher for the 500Mhz models.

2. Insert a USB memory stick with the MeasureStat.gz file into the USB port on the front panel.



3. Press the *Utility* key.

A grey rounded rectangle containing the word "Utility" in white text.

4. Press the *File Utilities* bottom from the bottom menu.

A blue rounded rectangle containing the text "File Utilities" in white.

5. Use the *Variable* knob to select the USB memory stick and then press the *Select* key.



6. Use the *Variable* knob to select MeasureStat.gz file and then press the *Select* key to select it.



Up ↗ Down ↘
VARIABLE



7. Press the *Select* key again to start installation.

Select

8. The installation is complete when a message showing "Please turn off the oscilloscope and turn on again" is displayed.

UNINSTALL THE SOFTWARE

Step


1. Press the *Test* key on the front panel.

Test

2. Press the *APP.* button from the bottom menu.

APP.

3. Use the *Variable* knob to select the Measurement Statistics APP.



4. Press the *Uninstall* button from the side menu.

Uninstall

5. Press the *Uninstall* button from side menu again to start the uninstallation process.

Uninstall

6. The uninstallation process is complete when a message showing "Please turn off the oscilloscope and turn on again" appears.

HOW TO USE THE SOFTWARE

Select an Auto Measurement

Step

1. Open the CH1 channel.


2. Press the *Measure* key on the front panel.




3. Press the *Add measurement* button from the bottom menu.




4. Press the *V/I* button from the side menu.




5. Use the *Variable* knob to select the *Pk-Pk* option. Press the *Select* key to confirm selection.





6. Use the *Variable* knob to select the RMS option. Press the *Select* key to confirm selection.



7. Press the *Time* button from the side menu.



8. Use the *Variable* knob to select the Frequency option. Press the *Select* key to confirm selection.



Open Measurement Statistics

Step

1. Press the *Statistics* button from the bottom menu.
2. Press the *Statistics ON/OFF* button from the side menu.

